









Solar PV Water Heater Quick Reference Guide



Dial Setting	Time on Mains*	Time on Solar*	24-Hour Clock
MAINS ONLY	24 hr	Never	
1	12:00 to 08:00	08:00 to 12:00	
2	14:30 to 05:30	05:30 to 14:30	
3	17:00 to 03:00	03:00 to 17:00	
SOLAR ONLY	Never	24 hr	

* Times are approximate – will vary slightly with season and location

< Attach Elon Serial Number Label Here >

Lights	Meaning
 Green light ON	Solar power available
 Green light flashing	Heating with solar
 Red light ON	Mains power available (power to Elon® X unit on)
 Red light flashing	Heating with mains
 Blue light ON	Geysers on temperature
 Red & Green light flashing fast	Isolation fault (contact electrician)
 All lights OFF	No power to unit (e.g.: no sun + power failure, or no sun + geyser breaker at DB switched off) OR supply voltage outside specifications

Note 1: Initial switch-on wait time for solar is **1 min** and for mains is **5 min**.
Note 2: Turning dial into “Mains Only” and back out will start mains heating cycle until geyser is on temp.

Note: lights function independently, so more than one light can be on at the same time.

